

## Wander ring Alert



### STX-WAND

The user wears a wristwatch transceiver with a call button. The receiver unit consists of a loop aerial fitted around the doorframe and across the threshold.

Active Call - Pressing the red button on the wrist transmitter generates a call.

Passive Monitoring - When the watch is close to the door, an alarm signal is transmitted to the carer informing them that the resident is leaving the building.

The system is intended to alert the carer of the location of a resident and in no way can it be used as a method of restraint.

## Wrist Alert



### STX-211

The Wristwatch transmitter is worn like a watch.

The user can generate an emergency call by pressing the pink button on the Wristwatch, which would then alert the carer that their attention is required.

The Wristwatch is splash resistant but should be removed when bathing or showering.